DATA SPEED S.R.L.
Str. Corneliu Coposu nr. 103, Cluj-Napoca, cod 400235, jud. Cluj
Tel: 0264 566 473, 0735 803 121
office@dataspeed.ro · www.dataspeed.ro

Indicator Cantarire DFWKXT



Indicator Cantarire DFWKXT, IP68 indicator de greutate cu multifunctie.

Descriere

.

- 17-key numerical and functional waterproof keypad.
- 25mm LCD backlit display with 6 high contrast digits with icons indicating the active functions.
- Easy to clean STAINLESS STEEL waterproof IP68 enclosure built to withstand harsh washdown and corrosive environments.
- Suitable for use on the table, column, or wall.
- Dimensions: 264x174x115mm.
- 24-bit A/D converter, 4 channels, up to 200 conv./sec. and up to 8 signal linearisation points.
- Up to 10.000e or multirange 3 x 3000e @ 0,3 µV/d in CE-M approved version for legal for trade use.
- Up to 800,000 displayable divisions with internal resolution up to 3.000.000 points.
- Digital calibration and set-up through keyboard or PC with DINITOOLS.
- Built-in rechargeable battery (60 hours with one 350-Ohm load cell) and power supply 110-240 Vac.
- Connectable with up to 8 350-Ohm load cells or up to 16 700-Ohm load cells.
- EC Type Approval (EN45501)
- OIML R76
- RS232/C port configurable for connection with printer/labeller, or for attached printer.
- RS232/C (or optionally RS485) bi-directional port configurable for PC, PLC, remote display, and radio modem.
- KEYBOARD: Zeroing, Automatic tare, Presettable tare, printing and/or data transmission, selectable function command, on/off switching, database of 10 tares, 2 Numeric IDs, keyboard lock, repetition of last printout made.
- SELECTABLE FUNCTIONS: - High Resolution Weighing x 10. - Net/Gross or lb/kg conversion. - Accumulation. - Formula weighing. - +/- Checkweighing. - Percentage weighing. - Approved transmission of the weight to PC/PLC or data recording on MMC/USB (with Alibi memory ALMEM option). - Counting(Max. resolution of 1.500.000 divisions). - In/Out Truck weighing. - Hold and Peak. - Set Point Control (with DFIO option).
- Infrared 19-key remote control: zero, tare / manual tare, enable / disable function, print, switch-off.
- Radiofrequency 6-key remote control: zero, tare, enable / disable function, print, switch-off.

Optional power supply cords

Junction Box / Boards - Cell cables

Approval

Storing the weighs (only at time of order)
Printers/Labellers
Communication Interfaces
Connection cables
Date&Time option
Control light
Weight repeaters
Columns, supports brackets, visors
Options for ATEX version
Remote control
.

Detalii: